

CONTENTS

Specifications Section 1 Introduction. 1 Section 2 Operating Procedure 3 Section 3 Calibration 9 Section 4 Service and Maintenance 11 Section 5 Type 1262-B Power Supply 18

Handbook of Noise Measurement

This 282-page book, by Dr. A. P. G. Peterson and Ervin E. Gross, Jr., of the General Radio Engineering Staff, covers thoroughly the subject of noise and vibration measurement. Copies are available from General Radio at \$1.00 each, postpaid in the United States and Canada.



Copyright 1968 by GENERAL RADIO COMPANY West Concord, Massachusetts USA 01781 Form 1551-0110-Q ID-1276 December, 1968

SPECIFICATIONS

Sound-Level Range: From 24 to 150 dB (re 20 µN/m²).

Frequency Characteristics: Four response characteristics, A, B, C, or 20 kHz, as selected by panel switch. The A-, B-, and Cweighting positions are in accordance with USA Standard S1.4-1961 and IEC Publication 123, 1961. Frequency response for the 20-kHz position is flat from 20 Hz to 20 kHz, so that complete use can be made of very wide-band microphones such as the 1551-P1 Condenser Microphone Systems.

Microphone: GR Type 1560-P5. Accessory condenser microphone is available.

Sound-Level Indication: Sound level is indicated by the sum of the meter and attenuator readings. The clearly marked, open-scale meter covers a span of 16 dB with calibration from --6 to +10 dB. The attenuator is calibrated in 10-dB steps from 30 to 140 dB above 20 μ N/m².

Calibration Accuracy: When amplifier sensitivity has been standardized, the absolute accuracy of sound-level measurements at 500 Hz is within \pm 1 dB and at all frequencies is in accordance with the USA Standard.

Panel adjustment is provided for standardizing amplifier gain with internal calibration circuit.

Absolute acoustic sensitivity is factory calibrated at 500 Hz. Microphone response and sensitivity are measured in a free field from 20 Hz to 15 kHz by comparison with a WE 640AA laboratorystandard microphone with calibration traceable to the National Bureau of Standards. Complete electrical frequency-response measurements are made on each instrument.

The 1562-A Sound-Level Calibrator or the 1559-B Microphone Reciprocity Calibrator can be used for making periodic over-all acoustic checks.

Output: 1.4 V behind 7000 Ω (panel meter at full scale). The output can be used to drive analyzers, recorders, oscilloscopes, and headphones. Harmonic distortion (panel meter at full scale) <1%.

Input Impedance: 25 M Ω in parallel with 50 pF.

Meter: Rms response, and fast and slow meter speeds in accordance with USA \$1.4-1961 and IEC 123, 1961.

Environmental Effects

Temperature and Humidity: Microphone is not damaged at temperatures from -30 to $+95^{\circ}$ C and relative humidities from 0 to 100%. When standardized by its internal calibration system or a 1562 Sound-Level Calibrator, the instrument will operate within catalog specifications (for panel-meter indications above 0 dB) over the temperature range of 0 to 60°C and the relative humidity range of 0 to 90%.

Magnetic Fields: When exposed to a 60-Hz, 1-oersted (80 A/m) field, the sound-level meter will indicate 60 dB (C weighting) when oriented for maximum sensitivity to the magnetic field.

Electrostatic Fields: Aluminum case provides sufficient shielding, so that normally encountered electrostatic fields have no effect. Vibration: Case is fitted with soft rubber feet and amplifier is resiliently mounted for vibration isolation. When the instrument is set on its feet on a shake table and vibrated at 10 mils pk-pk displacement over the frequency range of 10 to 55 Hz, the unwanted signals generated do not exceed an equivalent C-weighted sound-pressure level of 45 dB when motion is vertical, 60 dB when motion is lengthwise, or 40 dB when motion is sidewise.

SPECIFICATIONS (Con't)

GENERAL

Power Supply: Two 1½-V size D flashlight cells and one 67½-V battery (Burgess XX45 or equivalent) are supplied. An ac power supply, the Type 1262-B, is available.

Accessories Supplied: Telephone plug.

Accessories Available: 1551-P2 Leather Case (permits operation of instrument without removal from case), 1562 Sound-Level Calibrator, 1560-P95 Adaptor Cable for connecting output to 1521-B Graphic Level Recorder.

Mounting: Aluminum cabinet.

Dimensions (width x height x depth): 744 x 944 x 61/s in. (185 x 235 x 160 mm).

Weight, Net, 734 lb (3.6 kg); shipping, 16 lb (7.5 kg), batteries incl. Add 2 lb for leather case.

For a more detailed description, refer to General Radio Experimenter, August 1961.





TABLE OF CONTENTS

| Section 1. INTRODUCTION | |
|--|-----|
| 1.1 Purpose | • |
| 1.2 Description | • |
| 1.3 Power Supply | • |
| 1.4 Carrying Case | • |
| Section 2. OPERATING PROCEDURE | |
| 2.1 Preliminary Checks | |
| 2.2 Operating Procedure | • |
| 2.3 Selection of Weighting Network | • |
| 2.4 Sound Analysis and Recording | |
| 2.5 Extension Cable | |
| 2.6 Wide-Range Microphones, | |
| 2.7 Use of Headphones | |
| 2.8 Background Noise | |
| 2.9 Microphonics | |
| 2.10 Environmental Effects | |
| 2.11 Vibration Pickup | |
| 3.1 General | • |
| Section 4. SERVICE AND MAINTENANCE | |
| 4.1 General | . 1 |
| 4.2 Removal of Instrument from Cabinet | • |
| 4.3 Tube Failure | . 1 |
| 4.4 Tube Replacement | • |
| 4.5 Battery Replacement | • |
| 4.6 Replacement of Bias Cell | • |
| 4.7 Soldering of Connections to Cable Wires | . ' |
| 4.8 Microphone Sensitivity Adjustment | . ' |
| 4.9 Internal Noise | . ' |
| | |
| 4.10 Amplifier Gain | . ' |
| 4.10 Amplifier Gain. . | • |

.

Section 1 INTRODUCTION

1.1 PURPOSE. The Type 1551-C Sound-Level Meter (Figure 1) is the basic instrument of the General Radio sound-measuring system. This instrument conforms to all requirements of the ASA American Standard Specification for General Purpose Sound-Level Meters. An accurate, portable, low-priced meter, it indicates the sound-pressure level at its microphone in terms of a standard reference level ($0.0002 \mu bar$).¹

In addition to its primary use as a Sound-Level Meter, the Type 1551-C can be used as a highly sensitive ac voltmeter. With the microphone sensitivity adjustment (paragraph 4.8) set at -55.5 and the attenuator switch set at 30, the meter has a full-scale sensitivity of 30 microvolts. Voltages to be measured can be applied to the microphone connector through a Cannon three-terminal plug.

1.2 DESCRIPTION.

1.2.1 GENERAL. The major components of the Sound-Level Meter are a nondirectional microphone, a calibrated attenuator, an amplifier, an indicating meter, and weighting networks to modify the amplifier frequency response.

1.2.2 MICROPHONE. The Type 1560-P5 Microphone supplied with the Type 1551 Sound-Level Meter is a new piezoelectric ceramic microphone developed expressly for sound-level meter use. Several features of the Type 1560-P5 make it an excellent microphone for sound-level measurements:

¹0.0002 μ bar = 20 μ N/m²; cps = Hz.



Figure 2. Frequency response of Type 1560-P5 Microphone to sounds of random incidence.

1. a frequency characteristic (see Figure 2) carefully controlled in manufacture to give flat response to sounds of random incidence from $20\ {\rm cps}$ to $12\ {\rm kc}$,

2. rugged, dependable design, capable of withstanding wide climatic changes (from -30° to 200° F in temperature, from 0 to 100% relative humidity),

3. low temperature coefficient of sensitivity, with minimal change in output voltage from 0° to 200° F,

4. low temperature coefficient of internal impedance; the cable correction is not affected by temperature at the microphone.

The nominal internal impedance of the microphone is 380 pf.

1.2.3 CONTROLS AND CONNECTORS. The controls and connectors on the panel of the Sound-Level Meter are listed below.

| Name | Туре | Function |
|---------------------|---------------------------------------|--|
| Attenuator | 12-position selector switch | Selects meter range. |
| CAL | Thumb-set adjustment | Electrical internal calibration or gain adjustment. |
| METER- BATTERIES | 5-position selector switch | Selects fast or slow meter response; provides battery checks. |
| WEIGHTING | 5-position selector switch | Selects weighting. |
| OUTPUT | Phone jack | Output connection. |
| On-Off | Switch built into micro- phone arm | Turns instrument on and off (with battery power only). |
| None | 6-terminal Jones receptacle | Connection to Type 1262-B Power Supply. |

TABLE 1. CONTROLS AND CONNECTORS

1.3 POWER SUPPLY.

1.3.1 BATTERIES. Two Type D flashlight batteries supply the filament (A) power, and one 67-1/2-volt portable-radio-type B battery supplies the plate (B) power for the instrument. Contact is made to each battery by spring terminals, and all batteries are secured by a screw-down bracket.

1.3.2 AC POWER SUPPLY. The Type 1262-B Power Supply (refer to section 5) can be used to operate the Sound-Level Meter from a 115-volt ac line. When the Type 1262-B is used, its own power switch, rather than the microphone switch on the Type 1551-C, controls application of power to the Sound-Level Meter.

1.4 CARRYING CASE. Available for use with the Sound-Level Meter is a leather carrying case with shoulder straps. A hole in the back of this case matches the tapped hole in the back of the Sound-Level Meter so that the instrument can be secured in the case for field use. The cover flaps of the case are equipped with a luggage-type fastener to keep them closed over the panel and with snap buttons to hold them open when the instrument is in use.

Section 2

OPERATING PROCEDURE

2.1 PRELIMINARY CHECKS.

2.1.1 BATTERY CHECK. To check batteries, set the METER-BATTER-IES switch to FIL-1, turn the instrument on by raising the microphone, and check that the meter pointer is within the area marked BAT on the meter face. Turn the METER-BATTERIES switch to FIL-2 and then to PL, similarly checking that the meter pointer falls in the white BAT area for each position.

Filament batteries should last 6 to 7 days at 8 hours a day, or 30 to 35 days at 2 hours a day. Plate batteries should last 12 to 14 days at 8 hours a day, or 60 to 70 days at 2 hours a day.

2.1.2 CALIBRATION CHECK. Before using the Sound-Level Meter, make the following simple calibration check. (This check calibrates the amplifier of the Sound-Level Meter, but does not include a check on the microphone.)

a. Turn the instrument on.

b. Set the attenuator switch to 130 CAL (i.e., with the pointer on the knob toward the window).

c. Set the WEIGHTING switch to CAL, and check that the meter pointer falls within the white area marked CAL on the meter face. If not, set it there by adjusting the CAL thumbset control.

2.1.3 ACOUSTICAL CALIBRATION. The following over-all acoustical calibration can be made with the 1562 Sound-Level Calibrator. This calibration checks the microphone sensitivity as well as the amplifier sensitivity.

Perform the calibration check as described in paragraph 2.1.2. Then set the WEIGHTING switch to FLAT. Turn on the calibrator and set its frequency to 500 cps. Place the calibrator over the microphone. The sound-level meter should read 114 ± 0.5 dB (refer to paragraph 2.2). Switch the calibrator to each of its other frequencies. If the reading of the sound-level meter at 1000 cps is not between 113 and 115 dB, and/or if the readings at the various frequencies vary by more than ± 1 dB, it is possible that the microphone has been damaged; it should then be checked independently.

When the microphone is known to be in good condition, the gain of the sound-level meter can be calibrated by setting the meter reading to 114 dB at 1000 cps by means of the CAL control.

The above calibration will be made free of charge for any GR sound-level meter delivered to one of the General Radio offices listed elsewhere in this manual.

2.2 OPERATING PROCEDURE.

a. Turn the instrument on by raising the microphone (battery power) or by turning on the Type 1262-B (ac power).

b. Adjust the WEIGHTING switch for the desired frequency response. Refer to paragraph 2.3.

c. Adjust the attenuator switch for an on-scale deflection of the indicating meter. The sound level in decibels is the algebraic sum of the readings of attenuator dial and meter.

d. Set the METER-BATTERIES switch to FAST or SLOW depending on the type of meter response desired. The fast response is suitable for most noise measurements and for measuring minimum and maximum values of fluctuating sounds. The SLOW position provides a high degree of damping for measuring the average value of fluctuating sounds.

2.3 SELECTION OF WEIGHTING NETWORK. Many early noise criteria specified weighted sound levels, using this rule of thumb: A weighting for sound levels from 24 to 55 db, B for levels from 55 to 85 db, and C for levels from 85 to 140 db. (The appropriate range was selected after a preliminary C-weighted measurement.) More recent opinions favor selection of weighting network on the basis of the type of noise measurement; for instance, A weighting is often preferred for speech-interference measurements, while B is recommended for surveys of traffic noise. In the absence of specific weighting requirements, it is usually helpful to take measurements on all three weighting networks. For a full discussion of weighting networks, refer to the General Radio Handbook of Noise Measurement. Response curves for the various weighting networks, equalized for microphone response, are given in Figure 3.



Figure 3. Typical Acoustical and Electrical Response Curves for Type 1551-C.

If the Sound-Level Meter is to be used with an analyzer or recorder, set the WEIGHTING switch to 20 kc or to C. When an extended-range microphone is used in place of the microphone supplied with the instrument, use the 20 kc position.

2.4 SOUND ANALYSIS AND RECORDING. The low-distortion outputamplifier circuit of the Sound-Level Meter was designed especially for use with the Type 1558-A Octave-Band Analyzer and Type 1564-A Sound and Vibration Analyzer. Other analyzers, such as the Type 1900-A Wave Analyzer, can also be used. Connect the input of the analyzer or recorder to the OUTPUT phone jack on the Sound-Level Meter. For greatest accuracy, the impedance connected to the output circuit of the Sound-Level Meter should be about 20,000 to 25,000 ohms. The output impedance is 7000 ohms, and output voltage is 1.1 V into 20,000 ohms, 1.5 V opencircuit. Any load impedance can be connected across the output terminals.

The output system of the Sound-Level Meter can be used to drive a Type 1521 Graphic Level Recorder to obtain permanent records of sound measurements, or to operate a magnetic tape recorder to obtain field records that may be studied and analyzed later in the laboratory.

When recording or analyzing, set the attenuator switch so that the meter reads +6 db or more, if possible, to utilize the maximum dynamic range. If the meter reading falls below +6 db, it is sometimes desirable to set the attenuator switch one step lower, even if the meter pointer goes off scale as a result.

The internal calibration system of the Sound-Level Meter makes available, at the OUT jack, the 1000-cycle signal useful for setting the level of an analyzer or recorder to match that of the Sound-Level Meter.

2.5 EXTENSION CABLE. The Type 1560-P73*25-foot Extension Cable can be used to permit operation of the microphone at some distance from the meter. The extension cable introduces about 7 db loss. For best measurements this cable insertion loss should be determined by calibration with a Type 1562 Calibrator.

2.6 WIDE - RANGE MICROPHONES. The over-all frequency response characteristic of the Type 1551-C, with the WEIGHTING switch set at 20 kc, is essentially flat from 20 cps to 20 kc. (See Figure 4.) This permits use of such wide-range microphones as those used in the Types 1551-P1L and 1551-P1H Condenser Microphone Systems.

The Type 1551-P1L uses the Altec 21-BR-150 Condenser Microphone, useful over the sound-pressure range from 50 to 150 db. The Type 1551-P1H uses the Altec Type 21-BR-180 Microphone, useful from about 70 to 170 db. (When using the Type 1551-P1L, set the meter to 121 rather than 120 db in the calibration described in paragraph 2.1.3. When using the Type 1551-P1H, set the meter to 101 db and thereafter add 20 db to meter readings.) These microphones have a good frequency response from 20 cps to 18 kc.



*Also supplied as part of the Type 1560-P34 Tripod and 25-ft Cable Assembly.

Figure 4. Frequency Response of Type 1551-C Amplifier with WEIGHTING switch at 20 kc.

Also useful with the Type 1551-C over the range from 80 to 200 db is the Massa Type M-141F Standard Microphone, a piezoelectric microphone available from the Massa Laboratories Inc, Hingham, Mass. Its response is reasonably uniform up to 30 kc.

2.7 USE OF HE ADPHONES. If desired, a set of headphones can be plugged into the OUTPUT jack to monitor the sound being measured.

2.8 BACKGROUND NOISE. When possible, sound measurements should be made with negligible background noise - at least 10 db below the level being measured. However, this is not always possible, and Figure 5 is convenient in determination of errors caused by background noise.

2.9 MICROPHONICS. When high-intensity sound fields are being measured, it is good practice to use the microphone on the end of a cable (refer to paragraph 2.5) and to keep the Sound-Level Meter well removed from the sound field. This is especially true if the high-level noise contains frequencies of 1000 cps or higher. The following quick check will determine whether the tubes in the Type 1551-C are being excited microphonically: remove the microphone head, set the WEIGHTING switch to A, and check that there is no meter reading with the attenuator switch set at 70 db or higher.

At sound levels below 140 db no special vibration precautions should be necessary. The amplifier is resiliently mounted, vacuum tubes are resiliently mounted on the amplifier board, the amplifier cover is specially treated to reduce airborne sound transmission, and the instrument sits on soft rubber-feet.

When the Sound-Level Meter, with microphone replaced by an equivalent electrical impedance, is subjected to pure-tone sounds at a soundpressure level of 100 db re $0.0002 \mu bar$ at each frequency between 100 and 8000 cps, the output level in each octave band is at least 30 db below that for full-scale meter reading with the attenuator set for 100 db fullscale meter reading.

The Type 1551-C, with its microphone mounted on the panel microphone post, can measure sound pressure levels up to 140 db within the tolerances allowed in ASA S1.4, 1961. When the microphone is mounted on a cable, the maximum safe sound pressure level for the microphone is 150 db.

With an auxiliary high-level microphone separated from the Sound-Level Meter by a long cable to protect meter and operator from intense sound fields, levels up to 200 db can be measured.

2.10 ENVIRONMENTAL EFFECTS.

2.10.1 TEMPERATURE AND HUMIDITY. The Type 1560-P5 Microphone is not damaged at temperatures from -30° to $+95^{\circ}$ C and relative humidities from 0 to 100%. When standardized by its internal calibration system or a Type 1562 Sound-Level Calibrator, the Type 1551-C will operate within catalog specifications (for panel-meter indications above 0 db) over the temperature range from 0 to 60 C and the relative-humidity range from 0 to 80%.





The internal impedance of the microphone is capacitive, 475 pf at 25° C, varying from 445 to 510 pf from 0 to 50° C.

2.10.2 VIBRATION. The Type 1551-C case is fitted with soft rubber feet and the amplifier compartment is resiliently mounted for vibration isolation. When set on its rubber feet on a shake table and vibrated over the frequency range of 10 cps to 55 cps, the motion transmitted to the amplifier generates unwanted signals. The magnitude of these signals is listed in the table below.

| peak-to -peak | direct | tion of vil | oration | | |
|----------------------|--------|-------------|-------------|------|----|
| lisplacement | x | У | z | | |
| nches) | maxin | num meter | reading(db) | | |
| 0.030 | 65 | 70 | 55 | I YK | Ø |
| 0.010 | 45 | 60 | 40 | | -y |

2.10.3 MAGNETIC FIELDS. When exposed to a time-varying magnetic field of 1 oersted, the Type 1551-C will indicate 60 db when oriented for maximum sensitivity to the magnetic field.

2.10.4 ELECTROSTATIC FIELDS. The Type 1551-C is completely enclosed in an aluminum case so that the instrument is not affected by the electrostatic fields which are normally encountered.

2.11 VIBRATION PICKUP. It is often possible to measure the vibration amplitude, velocity, or acceleration of radiating surfaces. Useful vibration measurements can often be obtained where high ambient sound levels make acoustical measurements impossible. For vibration frequencies between 20 and 2000 cps, the Type 1551-C will operate as a vibration meter when used with a Type 1560-P11B Vibration Pickup System. With a Type 1560-P11S2 Vibration Pickup System (refer to the General Radio <u>Experimenter</u>, Volume 36, Number 11, November 1962), the Type 1551-C can be used for vibration measurements between 20 and 10,000 cps.

Refer to the General Radio <u>Handbook of Noise Measurement</u> for further information on vibration measurements.

Section 3

CALIBRATION

3.1 GENERAL. The calibration (acoustical and electrical) of the Type 1551-C Sound-Level Meter is carried out with pure tones. The Sound-Level Meter calibration is adjusted for random incidence sounds with the microphone mounted on the panel microphone post.

Microphone calibrations are made at 0 degrees (perpendicular incidence) in a free field with the microphone at the end of a cable. All microphone calibrations supplied by General Radio are at 0 degrees incidence. A correction curve is supplied to convert from 0 degrees to random-incidence response.

3.2 OBSERVER INFLUENCE. When measurements are made in reverberant or semireverberant fields, the observer and Sound-Level Meter case have a very small effect on the microphone response. Under freefield conditions and with a single sound source, both the observer and the case can have a large effect on microphone response (refer to the General Radio <u>Handbook of Noise Measurement</u>). These effects can be minimized if the instrument is held in front of the observer, with the observer oriented so that the sound passes in front of him at right angles to the axis of the Sound-Level Meter and its microphone.

For greatest accuracy it is recommended that the microphone be mounted on a tripod and connected to the Sound-Level Meter by an extention cable to keep the observer and the meter case out of the sound field being measured. 3.3 PREFERRED ANGLE OF INCIDENCE. When measurements are made on sounds in reverberant fields, the angle of incidence of sounds reaching the microphone is indeterminant. In this case there is no preferred angle of incidence between the microphone and the sound source. When measurements are made on a source in a free field, an angle of incidence of 70 degrees between the axis of the microphone and the sound source will approximate random response.

3.4 AUXILIARY CALIBRATION. The Type 1551-C has an internal calibrating system for quick checks on the electrical circuit of the instrument. This system connects the output of the amplifier to the input through an appropriate attenuator, filter, and limiter to produce a predetermined oscillation amplitude when the amplifier gain is correct. This system checks the electrical operation only and does not check the microphone. To make an acoustical check on the calibration of the instrument, the Type 1562 Acoustic Calibrator is recommended. This is a closed coupler with a driving loudspeaker that produces a known sound pressure level at the microphone.

3.5 METER CIRCUIT. The meter circuit used in the Sound-Level Meter, while not a true rms indicator, indicates much more closely to the rms value than have meters in earlier instruments. The meter circuit combines an average-reading circuit with a peak-reading circuit to create a "quasi-rms" indicating circuit. Since the rms value of most waveforms falls above the average value but below the peak value, a portion of the peak indication added to the average value of a given waveform should result in an rms indication. The meter circuit is designed to approximate rms values for various types of waveforms.

Table 2 below shows the db difference between the indication of a true rms meter and that of the Type 1551-C Sound-Level Meter for several test signals. In the column headed "db Fluctuation etc" the signal consists of two tones, one at 1000 cps set for a convenient meter indication. The other tone is within a few cycles of 3000 cps and has 30 percent of the amplitude of the first. A true rms meter will show no fluctuation with this type of signal. The column headed "For Two-Signal Addition" refers to the two-signal test outlined in ASA Standard Z24.3-1944.

With pulses of constant height but varying length, the Type 1551-C Sound-Level Meter indicates the rms value within ± 1 db until the pulse duration becomes as short as 1/25 that of a square wave.

| | | Difference in | Meter Indicati Decibels | on and RMS |
|---------------|--|-------------------------------|----------------------------|--------------|
| Type Meter | db Fluctuation with Phose Changes at 30% 3rd Harmonic | For Two-Signal Addition | For Square Waves | For Noise |
| 1551-C | 0.45 | +.05 | +0.1 | 0.25 |

TABLE 2.

Section 4 SERVICE AND MAINTENANCE

4.1 GENERAL. We warrant that each new instrument manufactured and sold by us is free from defects in material and workmanship, and that, properly used, it will perform in full accordance with applicable specifications for a period of two years after original shipment. Any instrument or component that is found within the two-year period not to meet these standards after examination by our factory, Sales Engineering Office, or authorized repair agency personnel, will be repaired, or, at our option, replaced without charge, except for tubes or batteries that have given normal service.

The two-year warranty stated above attests the quality of materials and workmanship in our products. When difficulties do occur, our service engineers will assist in any way possible. If the difficulty cannot be eliminated by use of the following service instructions, please write or phone our Service Department (see rear cover), giving full information of the trouble and of steps taken to remedy it. Be sure to mention the serial and type numbers of the instrument.

Before returning an instrument to General Radio for service, please write to our Service Department or nearest Sales Engineering Office, requesting a Returned Material Tag. Use of this tag will ensure proper handling and identification. For instruments not covered by the warranty, a purchase order should be forwarded to avoid unnecessary delay.

4.2 REMOVAL OF INSTRUMENT FROM CABINET. To remove the instrument from its cabinet, remove the two large black screws from the bottom of the cabinet and lift the cover off.

4.3 TUBE FAILURE. As tubes age, one or more of them may become open-circuited. Check the filament resistance with an ohmmeter between pins 3 and 5 of the tube base (see Figure 8). Make sure that the ohmmeter current through the filaments is less than 10 ma.

4.4 TUBE REPLACEMENT. For access to tubes, remove the two Phillipshead screws that attach the cover of the amplifier compartment, and lift off the cover. The tubes are held in place between rubber pads on the amplifier shelf and on the inside of the cover.

When replacing a tube, cut the leads on the new tube to between 5/16 and 3/8 inch before inserting the tube in the socket. Install the tube so that the red dot on the tube base is on the same side as that on the socket.

4.5 BATTERY REPLACEMENT. To replace any of the batteries, remove the black screw that secures the holding bracket. (See Figure 9.) After the bracket is removed, the batteries can be withdrawn and replaced. Observe proper polarity as marked, when replacing batteries.

4.6 REPLACEMENT OF BIAS CELL. For access to the bias cell, remove the two studs and washers from the ends of the amplifier etchedcircuit board. Pivot the amplifier shelf upward to expose the bias cell. To remove the bias cell, first pull the contacting clip sideways and away from the bias cell. The bias cell can then be unscrewed and replaced. When returning the amplifier shelf to its original position, be careful that all wires are free and that none will be pinched between shield and chassis.

4.7 SOLDERING OF CONNECTIONS TO CABLE WIRES. The plastic insulation on the wires in cables and on many interconnecting leads melts easily, and extreme caution is advised in soldering connections. If the wire is held with pliers near the spot to be soldered, heat will be carried away from the insulation, helping to avoid melted insulation.

4.8 MICROPHONE SENSITIVITY ADJUSTMENT. An internal sensitivity control is adjusted in the General Radio laboratory to match the characteristics of the microphone sent with each meter. If a microphone with a different sensitivity is substituted for that furnished, set this adjustment (see Figure 9) to indicate the new microphone sensitivity. Also, a check of acoustical calibration should be made by the method outlined in paragraph 2.1.3.

4.9 INTERNAL NOISE. Internal noise should not normally affect readings with the attenuator switch set at 40 or higher. If desired, the following procedure can be used to determine how much noise is generated in the instrument. Remove the microphone, and connect a 380-pf capacitor across terminals 1 and 3 of the microphone socket. This capacitor and its connecting leads must be completely shielded in a metal can connected to either the metal part of the microphone socket or to terminal 1, which is grounded. The connection is identical to that shown in Figure 7, except that a short circuit replaces the oscillator.



Figure 7. Circuit for Calibrating Amplifier Gain.

Be certain that there is no external pickup of any stray fields. The meter on the instrument should not read above -6 with the attenuator

switch set at 30, the WEIGHTING switch at C, and the METER BATTER-IES switch at FAST.

Internal noise can be caused by the bias cell, B50, or by the batteries. Tube noise is generally caused only by V50 or V52, which can be interchanged with V51 or V53 or replaced if less noise is required. It may be necessary to try several tubes to achieve a satisfactory reduction in noise. Typical noise levels arc given in the following table.

| 1551-C Attenuator | All Pass | | | NOISI OCTA | E LEV | ELS - d ND - c | lb ps | | | | |
|----------------------|-------------------|------|----|---------------|-------|-------------------|----------|------|------|------|-------|
| Setting db | 20 cps - 20 kc | 31.5 | 63 | 125 | 250 | 500 | 1000 | 2000 | 4000 | 8000 | 16000 |
| 30 | 17 | 25 | 26 | 28 | 30 | 30 | 30 | 28 | 26 | 27 | 29 |
| 40 | 27 | 35 | 36 | 38 | 40 | 41 | 40 | 38 | 36 | 37 | 39 |
| 50 | 37 | 45 | 46 | 48 | 50 | 51 | 50 | 48 | 46 | 47 | - 48 |
| 60 | 46 | 55 | 56 | 58 | 60 | 61 | 60 | 58 | 56 | 56 | 57 |
| 70 | 52 | 64 | 64 | 67 | 68 | 68 | 67 | 65 | 63 | 62 | 59 |
| 80 | 54 | 73 | 73 | 74 | 74 | 73 | 71 | 68 | 65 | 63 | 60 |
| 90 | 55 | 78 | 77 | 77 | 75 | 73 | 71 | 68 | 66 | 63 | 60 |
| 100 | 55 | 80 | 78 | 78 | 76 | 74 | 71 | 68 | 66 | 63 | 60 |
| 110 | 54 | 79 | 76 | 76 | 73 | 71 | 69 | 67 | 65 | 63 | 60 |
| 120 | 55 | 80 | 78 | 78 | 76 | 74 | 71 | 68 | 66 | 63 | 60 |
| 130 | 55 | 79 | 76 | 77 | 75 | 73 | 70 | 68 | 66 | 63 | 60 |
| 140 | 55 | 80 | 77 | 78 | 76 | 74 | 71 | 68 | 66 | 63 | 60 |

TYPICAL INTERNAL SIGNAL-TO-NOISE RATIOS C WEIGHTING (db BELOW FULL SCALE - SET FOR -60 db MICROPHONE)

4.10 AMPLIFIER GAIN. With the Sound-Level Meter set for normal operation with C weighting, apply a 1.0-volt, 400- or 1000-cycle signal to the microphone socket through a shielded 380-pf capacitor, as shown in Figure 7. The meter reading should agree with that given below for the sensitivity of the microphone used. (Microphone sensitivity is listed at the front of this manual, as well as on a label inside the instrument.)

| 1560-P3 (98108) Microphone Sensitivity db re 1 volt/µbar | Type 1551-C reading |
|--|---------------------|
| -62 | 136 |
| -61 | 135 |
| -60 | 134 |
| -59 | 133 |
| -58 | 132 |
| -57 | 131 |

4.11 TEST VOLTAGES AND RESISTANCES. The table on the following page lists dc voltages and resistances between tube and transistor pins and ground, as measured with a vacuum-tube voltmeter. For voltage measurements, set the attenuator to 130 CAL, the WEIGHTING switch to A, and the METER-BATTERIES switch to FAST. For resistance measurements, remove batteries and ground terminals 2, 3, and 4 of socket S02.

| TUBE (TYPE) | PIN | FUNC- TION | - VOLTS DC BTRY 1262-B | | RES TO GND |
|------------------|-----------------------|-----------------------|------------------------------------|------------------------------------|------------------------------------|
| V50 (CK512AX) | 1 2 3 4 5 | P S C G C | 15.0 15.0 0.71 -1.40 0 | 15.5 15.5 0.7 -1.41 0 | 890 k 890 k 16 * 0 |
| V51 (CK512AX) | 1 2 3 4 5 | P S C G C | 16.0 14.1 1.45 0 0.72 | 16.1 14.2 1.41 0 0.71 | 320 k 940 k 0 1 M 16 |
| V52 (CK512AX) | 1 2 3 4 5 | P S C G C | 9.4 9.4 0.76 -0.48 0 | 9.1 9.1 0.76 -0.48 0 | 850 k 850 k 16 18 M 0 |
| V53 (CK512AX) | 1 2 3 4 5 | P S C G C | 21.5 14.9 1.44 0 0.76 | 20.5 14.3 1.4 0 0.73 | 340 k 1.21 M 0 18 M 16 |
| V54 (CK6418) | 1 2 3 4 5 | P S C G C | 17.2 17.6 1.48 -0.35 0 | 16.3 17.0 1.42 -0.35 0 | 123 k 400 k 0 18 M 0 |
| V55 (CK6418) | 1 2 3 4 5 | P S C G C | 14.5 21.5 1.47 -0.22 0 | 13.9 20.7 1.37 -0.22 0 | 100 k 270 k 0 18 M 0 |
| TR1 (2N1372) | 1 2 3 | E B C | 14.3 14.2 0 | 13.0 12.9 0 | 30 k 96 k 0 |
| RX51 S02 | К 4 | | 40. 2 65. 0 | 39.7 59 | |

TABLE OF VOLTAGES AND RESISTANCES.

*Do not attempt to measure (bias cell in circuit).

| | F | PARTS LIST | ſ | | |
|------------|---|------------------------|-------------------|--------------------------------|-------------------|
| Ref. No. | Description | GR Part No. | Fed, Mfg. Code | Mfg, Part No. | Fed. Stock No. |
| CAPACITO | DRS | | | | |
| C2 | Mica, 330 pF ±2% 500 V | 4690-3200 | 00656 | CM20E, 300 pF ±2% | 5005-858-4040 |
| C3 | Trimmer. $7 = 45 \text{ pF}$ | 4910-0100 | 24035 72982 | TSAN300 7-45 pF | 5905-656-4049 |
| C4 | Mica, 30 pF ±2% 500 V | 4690-0400 | 00656 | CM20E, 30 $pF \pm 2\%$ | 0,10 1,7 ,2,0 |
| C5 | Mica, 90.0 pF ±2% 500 V | 4690-1201 | 00656 | CM20E, 90.9 pF ±2% | |
| C7 | Plastic, 0.0033 μ F ±2% 200 V | 4860-7350 | 84411 | 663UW, 0.0033 μF ±2% | |
| C8 C9 | Mica, 178 pF $\pm 2\%$ 500 V | 4690-2217 | 00656 | CM20E, 178 pF $\pm 2\%$ | |
| C10 | Plastic, $0.0332 \mu\text{F} \pm 2\% 100 \text{ V}$ | 4090-2217 | 00050 84411 | 663UW 0.0332 HF ±2% | |
| C11 | Mica, 220 pF ±2% 500 V | 4690-2700 | 00656 | CM20E221G | 5910-931-4153 |
| C12 | Wax, 0.47 µF ±10% 100 V | 5010-3600 | 80183 | 78P4741S3 | 5910-448-5765 |
| C13 | Electrolytic, 60 µF 25 V | 4450-2900 | 56289 | D17872 | 5910-799-9280 |
| C15 C16 | Ceramic, 12 pF ±5% 500 V (NPO) Mice 35 pE ±2% 500 V | 4400-3200 | 00656 | Type CL-1, 12 pF ±5% | 5910-705-6442 |
| C19 | Mica, $0.001 \ \mu\text{F} \pm 5\% \ 500 \ \text{V}$ | 4580-0100 | 14655 | 5A. 0.001 $\mu F \pm 5\%$ | 5910-052-7016 |
| C20 | Mica, 0.001 μF ±5% 500 V | 4580-0100 | 14655 | 5A, 0.001 μ F ±5% | 5910-052-7016 |
| C21 | Mica, 0.0012 μF ±5% 500 V | 4580 -020 0 | 14655 | 5A, 0.002 μF ±5% | |
| C22 | Mica, 0.001 μ F ±5% 500 V | 4580 - 0100 | 14655 | 5A, 0.001 µF ±5% | 5910-052-7016 |
| C23 C50 | $M_{NN} = 0.1 \text{ uF} \pm 10\% 100 \text{ V}$ | 4860-7319 | 54411 | 003UW, U.UU158 μF ±1% | 5010-448-5758 |
| C51 | Wax, 1 μ F ±10% 100 V | 5010-2700 | 80183 | 78P10571S3 | 5910-615-5255 |
| C52 | Electrolytic, 50 µF 50 V | 4450-2200 | 80183 | 50 μF +100-10% | 5910-799-9283 |
| C53 | Wax, 0.22 µF ±10% 100 V | 5010-3300 | 80183 | 78P22411S3 | 5910-448-5777 |
| C54 | Wax, 0.1 µF ±10% 100 V | 5010-2700 | 56289 | 78P10491S3 | 5910-448-5758 |
| C55 | Wax, 0.22 µF ±10% 100 V | 5010-3300 | 80183 | 78P22411S3 | 5910-448-5777 |
| C57 | Electrolytic, $30 \mu\text{F}$ 100 V | 5010-3300 | 37042 | 78P2241153 95947C7523C10X3 | 5910-440-5777 |
| C58 | Wax, 0.01 µF ±10% 100 V | 5010-1600 | 80183 | 78P1031S3 | 5910-448-5788 |
| C59 | Wax, 0.1 µF ±10% 100 V | 5010-2700 | 56289 | 78P10491S3 | 5910-448-5758 |
| C60 | Wax, 0.1 µF ±10% 100 V | 5010-2700 | 56289 | 78P10491S3 | 5910-448-5758 |
| C61 C61 | Wax, 0.01 µF ±10% 100 V | 5010-1600 | 80183 | 78P1031S3 | 5910-448-5788 |
| C63 | Wax, $0.22 \ \mu F \pm 10\% \ 100 \ V$ | 5010-3300 | 80183 | 78P474153 78P474153 | 5910-448-5765 |
| C64 | Plastic, 0.0606 μ F ±2% 100 V | 4860-8213 | 84411 | $663UW, 0.0606 \mu F \pm 2\%$ | 0,10 110 0,00 |
| C65 | Wax, 1 µF ±10% 100 V | 5010-3700 | 80183 | 78P10571S3 | 5910-615-5255 |
| C66 | Wax, 0.047 μF ±10% 100 V | 5010-2100 | 56289 | 78P4731S3 | |
| C67 | Wax, $0.47 \mu\text{F} \pm 10\% 100 \text{V}$ | 5010-3600 | 80183 | 78P4741S3 | 5910-448-5765 |
| C69 | Wax, $0.47 \ \mu\text{F} \pm 10\% 100 \ \text{V}$ | 5010-3600 | 80183 | 78P474153 78P474153 | 5910-446-5765 |
| C70 | Electrolytic, 16 uF 150 V | 4450-0200 | 37942 | D33104 | 5910-829-3313 |
| C71 | Ceramic, 3.3 pF ±10% 500 V | 4400-0400 | 78488 | GA, 3.3 pF ±10% | 5910-708-5197 |
| RESISTO | RS | | | | |
| R1 | Film, 22.9 MΩ ±1% 1 W | 6182-5229 | 03888 | PT1000, 22.9 MΩ ±1% | |
| RZ D2 | Film, 2.17 MW $\pm 1\%$ 1/2 W | 6450-4217 | 75042 | CEC, 2.17 M $\Omega \pm 1\%$ | |
| R4 | Film, 1.0 M Ω ±1% 1/8 W | 6250-3333 | 75042 | CEA. 1 MQ $\pm 1\%$ | 5905-646-5678 |
| R5 | Film, 659 kΩ ±1% 1/8 W | 6250-3659 | 75042 | CEA, 659 k $\Omega \pm 1\%$ | |
| R6 | Film, 73.2 k $\Omega \pm 1\% 1/8$ W | 6250 - 2732 | 75042 | CEA, 73.2 kΩ ±1% | 5905-655-1982 |
| R7 | Film, 500 k Ω ±1% 1/8 W | 6250-3500 | 75042 | CEA, 500 k Ω ±1% | 5905-783-8446 |
| R8 P0 | Film, $159 \text{ k}\Omega \pm 1\% 1/8 \text{ W}$ | 6250~3159 | 75042 | CEA, 159 k $\Omega \pm 1\%$ | |
| RIO | Film, 50 k Ω ±1% 1/8 W | 6250-2500 | 75042 | CEA, 50 kΩ $\pm 1\%$ | |
| RII | Film, 154 k $\Omega \pm 1\%$ 1/8 W | 6250-3154 | 75042 | CEA, 154 k Ω ±1% | |
| R12 | Film, 15.9 kΩ ±1% 1/8 W | 6250-2159 | 75042 | CEA, 15.9 kΩ ±1% | |
| R13 | Film, 169 k Ω ±1% 1/8 W | 6250-3169 | 75042 | CEA, 169 k $\Omega \pm 1\%$ | 5905-892-6921 |
| R14 R15 | Film, 7.32 KW #1% 1/8 W Film, 63 3 kO +1% 1/9 W | 6250-1732 | 75042 | UEA, 7.32 KΩ $\pm 1\%$ | 5905-578-0994 |
| R16 | Film, 216 k Ω ±1% 1/8 W | 6250-3216 | 75042 | CEA, 216 k0 $\pm 1\%$ | |
| R17 | Film, 100 k $\Omega \pm 1\%$ 1/8 W | 6250-3100 | 75042 | CEA, 100 k $\Omega \pm 1\%$ | 5905-577-6743 |
| R18 | Composition, 100 k Ω ±5% 1/2 W | 6100-4105 | 01121 | RC20GF104J | 5905~195~6761 |
| K20 | Composition, 110 k Ω ±5% 1/2 W | 6100-4115 | 01121 | RC20GF114J | 5905-279-1867 |
| R23 | Composition, $75 \text{ KM} \pm 5\% 1/2 \text{ W}$ | 0100-3755 6100-4625 | 01121 | RC20GE/53] RC20GE6241 | 5905-279-3495 |
| R24 | Composition, $3 k\Omega \pm 5\% 1/2 W$ | 6100-2305 | 01121 | RC20GF3024J | 5905-279-1751 |
| R25 | Composition, 11 kΩ ±5% 1/2 W | 6100-3115 | 01121 | RC20GF113] | 5905-279-2667 |
| R26 | Composition, $3 k\Omega \pm 5\% 1/2 W$ | 6100-2305 | 01121 | RC20GF302J | 5905-279-1751 |
| K27 | Composition, $3 k\Omega \pm 5\% 1/2 W$ | 6100-2305 | 01121 | RC20GF302J | 5905-279-1751 |
| n20 R29 | Film, 10.9 KW =1% 1/2 W Film, 16.9 k0 ±1% 1/2 W | 6250-2169 | 75042 | UEA, 10.9 KΩ $\pm 1\%$ | 5905-806-8487 |
| R30 | Composition, 820 k $\Omega \pm 5\%$ 1/2 W | 6100-4825 | 01121 | CEA, 10.7 KW ±1% RC20GF8241 | 5905-221-58487 |
| R31 | Composition, 20 k Ω ±5% 1/2 W | 6100-3205 | 01121 | RC20GF2031 | 5905-192-0649 |
| R32 | Composition, $43 \text{ k}\Omega \pm 5\% 1/2 \text{ W}$ | 6100-3435 | 01121 | RC20GF433] | 5905-279-3498 |
| R33 | Composition, 24 k Ω ±5% 1/2 W | 6100-3245 | 01121 | RC20GF243J | 5905-279-1878 |
| K34 R35 | Potentiometer, composition 50 k $\Omega \pm 10\%$ | 6010-1400 | 01121 | JU, 50 k Ω ±10% | 5905-055-3046 |
| R36 | Composition, 330 KW $\pm 5\%$ 1/2 W | 6100-2245 | 01121 | KC2UGF334J RC20CE2431 | 5905-279-2519 |
| R37 | Composition, 51 k Ω ±5% 1/2 W | 6100-3243 | 01121 | RC20GF243J | 5905-279-3496 |
| R38 | Potentiometer, composition 100 k $\Omega \pm 10\%$ | 6010-1700 | 01121 | $[U, 100 \ k\Omega \pm 1\%]$ | 5905-797-1054 |
| R39 | Potentiometer, composition 100 k $\Omega \pm 20\%$ | 6040-1000 | 01121 | FWC, 100 k $\Omega \pm 20\%$ | 5905-958-7949 |
| R40 | Composition, 1.0 MΩ ±5% 1/2 W | 6100-5105 | 01121 | RC20GF105J | 15905-192-0390 |

| | PAR | TS LIST (Con | t) | | |
|-------------|---|-----------------------------|-------------------|-------------------------|--------------------------------|
| Ref. No. | Description | GR Part No. | Fed. Mfg. Code | Mfg, Part No. | Fed. Stock No. |
| RESISTOR | IS (Cont) | (100 1/05 | ~ | | 5005 050 0510 |
| *K50 R51 | Composition, 430 kM $\pm 5\%$ 1/2 W | 6100-4435 | 01121 | RC20GF434J | 5905-279-2518 |
| R51 R50 | Composition, 110 KM $\pm 5\%$ 1/2 W | 6100-4115 | 01121 | RC20GF114J | 5905-279-1807 |
| K52 D52 | $F_{11}m$, $I_{MM} = 1\% I/8 W$ | 0250-4100 | 75042 | CEA, $IM\Omega \pm I\%$ | 5905-040-5070 |
| R55 DE4 | Composition, 910 KM $\pm 5\%$ 1/2 W | 0100-4915 | 01121 | RC20GF914J | 5905-221-5053 5005 171 1009 |
| R54 DFE | E_{1} 200 k0 ±10 1/2 W | 0100-3335 | 01121 | RC20GF333J | 5905-1/1-1990 |
| R33 *DE4 | C_{11111} , 270 KM -1% 1/8 W | 6250-5250 | 75042 | CEA, 290 KM ±1% | F00F-270-2502 |
| * 057 | Composition, 10 MM $\pm 5\%$ 1/2 W | 6100-6185 | 01121 | RC20GF180J | 5905-279-2303 |
| DEO | Composition, 750 kM $\pm 5\%$ 1/2 W | 6100-4/55 | 01121 | RC20GF754j | 5905-279-1757 5005-105-4741 |
| N30 D50 | Composition, 100 kM $\pm 5\%$ 1/2 w | 6100-4105 | 01121 | RC20GF104j | 5905-195-0701 |
| *P40 | Composition, 18 Ma $\pm 5\%$ 1/2 W | 6100-0185 | 01121 | RC20GF100j | 5905-279-2303 5005-171-2000 |
| R00 P61 | Composition 1.2 MO ±5% 1/2 W | 6100-4065 | 01121 | RC20GF004j | 5905-190-2000 |
| R61 | Composition, 1.2 Miz $\pm 5\%$ 1/2 W | 6100-4225 | 01121 | RC20GF125j | 5905-190-0874 |
| R02 D62 | Composition, 19 MO $\pm 6\%$ 1/2 W | 6100-4333 | 01121 | RC20GF434j | 5005-279-2510 |
| R03 | Composition, 10 $W12 \pm 5\% 1/2 W$ | 6100-0105 | 01121 | RC20GF100j | 5905-279-2505 |
| * 0 4 5 | Composition, $390 \text{ KM} \pm 5\% 1/2 \text{ W}$ | 6100-4395 | 01121 | RC20GF394J | 5905-279-2517 ED05-270-1847 |
| P66 | Potentionator accuracition 2 5 10 4100 | 6040-1700 | 01121 | RC20GF114J | 3903-279-1007 |
| K00 *D47 | Composition 200 O ±50 1/2 W | 6100-1205 | 01121 | PC20CE2011 | 5005-270-5491 |
| -R07 | Composition, $300.42\pm5\%$ 1/2 W | 0100-1305 | 01121 | RC20GF301J | 5905-479-5461 |
| R00 | Composition, 10 KM $\pm 3\%$ 1/2 W | 6100-6105 | 01121 | RC20GF103J | 5905-103-0510 |
| R09 | Composition, 220 KM $\pm 5\%$ 1/2 W | 6100-4225 | 01121 | RG20GF224j | 5905-192-0007 |
| R/U D71 | Composition, 18 MM ±5% 1/2 W | 6100-6185 | 01121 | RC20GF100j | 5905-279-2503 |
| R/1 D70 | Composition, 2.4 MM 25% 1/2 W | 6100-5245 | 01121 | RC20GF245J | 5905-279-2512 |
| R72 R72 | Composition, $300 \text{ kM} \pm 5\% 1/2 \text{ W}$ | 6100-4305 | 01121 | RC20GF304j | 5905-103-0039 |
| R/3 P/74 | Composition, 100 kM $\pm 5\%$ 1/2 W | 6100-4105 | 01121 | RC20GF104J | 5905-195-0701 |
| R/4 D75 | Composition, $120 \text{ k} = 5\% 1/2 \text{ W}$ | 6100-4125 | 01121 | RC20GF124j | 5905-192-3901 |
| R/5 D74 | Composition, $470 \text{ KM} \pm 5\% 1/2 \text{ W}$ | 0100-44/5 | 01121 | RC20GF4/4J | 5905-279-2515 |
| R/0 | Composition, 10 kM $\pm 5\%$ 1/2 W | 6100-5105 | 01121 | RC20GF103J | 5905-105-0510 F005 102 0640 |
| 1.77 | Composition, 20 KM 15% 1/2 W | 0100-3203 | 01121 | KC20G1-203J | 3703 172 0047 |
| MISCELLA | ANEOUS | | | | |
| BI | Battery, 1-1/2 V Type D cell | 8410 -0 200 | 77542 | 21.P | |
| B2 | Battery, 1-1/2 V Type D cell | 8410 -0 200 | 77542 | 2LP | |
| B3 | Battery, 67-1/2 V | 8410-2300 | 09823 | XX45 | |
| B50 | Battery, 1-1/2 V | 4020-0100 | 90303 | BC4 | |
| D1 | Diode, type 1N34A (S) | 6082-1003 | 82389 | #111 | |
| D2 | Diode, type 1N34A (S) | 6082-1003 | 40931 | MEDS-105 | 6625-708-5186 |
| D3 | Diode, type 1N34A (S) | 6082-1003 | 71785 | P-302-AB | |
| D4 | Diode, type 1N34 A (S) | 6082 - 1003 | 58854 | IN34A(S) | 5961-170-4430 |
| D5 | Diode, type 1N645 | 6082-1016 | 58854 | IN34A(S) | 5961-170-4430 |
| D6 | Diode, type 1N645 | 6082-1016 | 58854 | IN34A(S) | 5961-170-4430 |
| JI | Jack | 4260-1500 | 58854 | IN34A(S) | 5961-170-4430 |
| MI | Meter, 100 µa dc | 5730-1050 | 24446 | IN645 | 5961-944-8222 |
| PLI | Plug | | 24446 | IN645 | 5961-944-8222 |
| QI | Transistor, type 2N1372 | 8210-1372 | 86800 | IN976B | 5960-854-8469 |
| RX51 | Diode, type 1N967B | 6 0 83 -1 020 | 76854 | 179901-H4C | |
| SI | Switch | 7890-1600 | 76854 | 179901-H4C | |
| 52 | Switch | 7890-1600 | 24655 | /890-1530 | 5930-708-5199 |
| 53 | Switch | /890-1530 | 24655 | 1551-0450 | 5930-708-5198 |
| 54 | Switch, DPS I | 1551-0450 | 24655 | 4230-2840 | |
| SOI | Socket | 4230-2840 | 71785 | 5-306-AB | |
| 502 | Socket | 4230-3500 | 01295 | ZIN1372 | 50/0 501 0-2- |
| V 50 | 1 we | 8370-1400 | 94144 | UK512AX | 5960-581-9593 |
| V51 | LUDC The back | 8370-1400 | 94144 | CK512AX | 5960-581-9593 |
| V52 | 1 uDe | 8370-1400 | 94144 | UK512AX | 5960-581-9593 |
| 1754 | 1 upe | 8370-1400 | 94144 | CK51ZAX | 5960-581-9593 |
| V54 V55 | Tube | 8380-6418 | 94144 | CK0418 | 5960-537-3967 |
| V 22 | Tube | 8380-6418 | 94144 | CK0418 | 5960-537-3967 |

*Must be Allen-Bradley.

MECHANICAL PARTS LIST

| Fig. 8 Ref. | Name | Description | GR Part No. | Fed. Mfg. Code | Mfg, Part No. | Fed. Stk. No. |
|----------------|--------------|-------------------------------|----------------|-------------------|---------------|------------------|
| 1 | Microphone | Piezoelectric-Ceramic | 1560-9605 | 24655 | 1560-9605 | |
| 2 | Knob Asm. | Knob, attenuator; includes | | | | |
| | | bushing 4140-0300 | 5530-1200 | 24655 | 5530-1200 | 5355-926-5196 |
| 3 | Knob Asm. | Knob, WEIGHTING; includes | | | | |
| | | bushing 4140-0300 | 5500-0400 | 24655 | 5500-0400 | 5355-051-6594 |
| 4 | Thumbset | CAL control | 5540-2500 | 24655 | 5540-2500 | |
| 5 | Support | Black rubber | 5260-1600 | 24655 | 5260-1600 | |
| 6 | Knob Asm. | Knob, METER/Batteries; | | | | |
| | | includes bushing 4140-0300 | 5500-0400 | 24655 | 5500-0400 | 5355-051-6594 |
| 7 | Meter Cover* | ME3-701 Cover; Dark Gray Mask | 5720-3712 | 24655 | 5720-3712 | |
| 8 | Foot | Block rubber | 5250-1902 | 24655 | 5250-1902 | |
| (Hidde | m) | | | | | |
| 9 | Handle | Leather strap handle | 1551-0460 | 24655 | 1551-0460 | |
| | | • | | | | |

*When ordering, please specify manufactured by Weston or Honeywell.



滋 漁 Allenia Allenia , T 1468-181 - 394 46-14 10 miles ŝ. 2008 14**11** 22 282 9-940 2-825 9-825 9-825 9-825 Ŷ and a 22. तत्वी 🕷 dif Samit 2374 2374 989 87

Planet R. Externel received and sorts of fee. Second income there.

> The second state of the second states and states for more could be the states. The Second states of the could states are states at the states. This result must be a loss of states states at the states of the states in the second states at the states of the states of the states and states at the states of the states in the states and states are stated at the state of the states are stated at the states at the state of the states are states and states are stated at the states at the states are stated at the state of the states at the states at the states at the states of the states at the states at the states at the states of the states at the states at the states at the states of the states at the states at the states at the states of the states at the states at the states at the states of the states at the states at the states at the states of the states at the states a

Type: 3. Sciences Constant, Type: MistaC Soundal event Names,





Rotary switch sections are shown as viewed from the panel end of the shaft. The first digit of the contact number refers to the section. The section neorest the panel is 1, the next section bock is 2, etc. The next two digits refer to the contact. Contact 01 is the first position clockwise from o strut screw (usu-ally the screw obove the locating key), and the other contocts are numbered sequentially (02, 03, 04, etc), proceeding clockwise around the section. A suffix F or R indicates that the contact is on the front or rear of the section, respectively.

NOTE

- RESISTORS 1/2 WATT UNLESS OTHERWISE SPE RESISTANCE IN OHMS UNLESS OTHERWISE . K=1000 OHMS M=1 MEGOHM
- CAPACITANCE VALUES ONE & OVER IN MICRO LESS THAN ONE IN MICROFARADS UNLE OTHERWISE NOTED.
- SCREW DRIVER ADJUSTMENT PANEL CONTROL 0



NOTE:

RESISTORS 1/2 WATT UNLESS OTHERWISE SPECIFIED RESISTANCE IN OHMS UNLESS OTHERWISE SPECIFIED K=1000 OHMS M=1 MEGOHM

- CAPACITANCE VALUES ONE & OVER IN MICRO[®] MICROFARAOS, LESS THAN ONE IN MICROFARADS UNLESS OTHERWISE NOTED.
- SCREW DRIVER ADJUSTMENT PANEL CONTROL 00

Figure 9. Schemati Type 1551-C Sound-L



Figure 9. Schematic Diagram, Type 1551-C Sound-Level Meter.

Factor III. Interior State, Yota UNI-E Shandrich of Matter



Figure 11. Companyet Copert on Excludibrard. Complete boord in 1974 1000-2015

NEW The mean we prove that the state of the property proves the state of the state of

38



Section 5 TYPE 1262-B POWER SUPPLY

5.1 DESTRICLATION. Referen subspites Cype 1260-5 Prover Supply, re-movemble latitucies from the format-formal Materia forfait to paragraph 4.33, and replace the found -terrel Materia in the case.
To annuch the prover supply to the Scord-Level Meter, it is associative to the sound terrel Materia in the sound region. This is associated to the sound terrel Materia in the intervent for the sound terrel Materia.
The sound terrel institute for the intervent english wheat the proven supply the terrel Materia.
The sound terrel institute for the intervent english wheat the format terrel Materia.
The sound terrel institute for the intervent english wheat the format terrel Materia.
Annual Materia institute terrel basers and the sound terrel for the sound terrel Materia.
The sound terrel institute terrel basers and terrel for the sound terrel Materia.
Annual Materia institute terrel basers.
Annual Materia institute terrel basers and terrel basers and the sound terrel Materia.
Annual Materia institute terrel basers.
Annual Materia institute terrel basers and terrel basers.
Annual Materia institute terrel basers and terrel basers and terrel basers.
Annual Materia institute terrel basers and terrel basers.</p

1.3. GENERATION: Communication Transmission (Comparison of the Comparison of the

3.3 SERVICE AND MAINTENANCE. Ester to paragraph 4.4,

4.4 MORSE LEVEN. The internal conservers of the Subard-Lords Lister dependent on the question of the second sec

If the finite-Lovid Metter is opposited in an area where the line-versing thermore sharpship and repositedly for most devices excitate spec-mediate d₁ the internal sense level will appear to be bighter then the releven lighted sharps.



R75



BLOCK





Section 5

TYPE 1262-B POWER SUPPLY

5.1 INSTALLATION. Before using the Type 1262-B Power Supply, remove the batteries from the Sound-Level Meter (refer to paragraph 4.5), and replace the Sound-Level Meter in its case.

To attach the power supply to the Sound-Level Meter, it is necessary first to remove the cover from the power supply. To do this, loosen the two 10-32 screws at the ends of the power supply. Then slide the cover off, i.e., away from the engraved panel of the power supply.

Two 1/4-28 binder-head screws are used to attach the power supply to the Sound-Level Meter. Insert these screws through holes in the back of the power supply and mating threaded holes in the Sound-Level Meter. The six-terminal male connector in the power supply should slip into the receptacle on the Sound-Level Meter.

5.2 OPERATION. Connect the Type 1262-B input plug to a 105-125 (or 210-250) -volt, 50-60-cycle power source. Turn the Power Supply and Sound-Level Meter on by means of the power supply on-off switch. (The Sound-Level Meter's on-off switch functions only when the instrument is battery-operated.) To check for proper operation, set the METER-BATTERIES switch to PL and FIL, checking that for each position the meter pointer falls within the white BAT area on the meter face.

5.3 SERVICE AND MAINTENANCE. Refer to paragraph 4.1.

5.4 NOISE LEVEL. The internal noise level of the Sound-Level Meter depends on the quality of the power line supplying the Type 1262-B Power Supply. With a good line (i.e., no transient humps or frequency components below 50 cps), the noise level will be 28 db or less for the 20-kc weighting position, below 26 db with C weighting, and below 24 db with A or B weighting.

If the Sound-Level Meter is operated in an area where the line voltage fluctuates abruptly and repeatedly (e.g. near devices such as spot welders), the internal noise level will appear to be higher than the values listed above.





Figure 13. Schematic Degree, Type 1262-8 Power Supply.



Tι

| | | GR | Fed, Mfg. | | Fed. Stock |
|---------------------|---|-----------|-----------|---------------------|---------------|
| LEF, NO, CARACIT | Description | Part No. | Code | Mfg. Part No. | No. |
| CLA | 013 | | | | |
| CIR | Electrolytic, 300 µF 35 V | 4450-2400 | 37942 | 2021149S4C10X1 | 5910-822-2691 |
| C2A | 1200 | | | | |
| C2B | Electrolytic, 2400 µF 15 V | 4450-4200 | 37942 | 20-21339-99-6 | |
| C2C | 1200 | | | | |
| C3A | 200 | | | | |
| C3B | Electrolytic block, 100 µF 100 V | 4460-1500 | 80183 | DFP, 200/100/100 µF | 5910-822-2692 |
| C3C | 100 | | | | |
| C4A | Electrolytic, 300 µF 35 V | 4450-2400 | 37942 | 2021149S4C10X1 | 5910-822-2691 |
| C4B | | | | | |
| PILOT LA | MP | | | | |
| P 1 | 115 V | 8390-0600 | 24446 | NE-51 | 6240-223-9100 |
| | | | | | |
| RESISTO | RS | | | | |
| R1 | Composition, 100 k Ω ±5% 1/2 W | 6100-4105 | 01121 | RC20GF104J | 5905-195-6761 |
| R2 | Composition, 200 $\Omega \pm 5\% 1/2$ W | 6100-1205 | 01121 | RC20GF201J | 5905-279-2674 |
| R3 | Composition, 130 $\Omega \pm 5\% 1/2$ W | 6100-1135 | 01121 | RC20GF131J | 5905-252-5436 |
| R4 | Composition, 43 Ω ±5% 1/2 W | 6100-0435 | 01121 | RC20GF430J | 5905-279-1887 |
| R5 | Composition, 47 Ω ±5% 1/2 W | 6100-0475 | 01121 | RC20GF470J | 5905-252-4018 |
| R6 | Composition, 180 Ω ±5% 1/2 W | 6100-1185 | 01121 | RC20GF181J | 5905-279-3514 |
| R7 | Composition, 1.5 k Ω ±5% 1/2 W | 6100-2155 | 01121 | RC20GF152J | 5905-841-7461 |
| R8 | Composition, 1.5 k Ω ±5% 1/2 W | 6100-2155 | 01121 | RC20GF152J | 5905-841-7461 |
| R9 | Composition, 51 kΩ ±5% 1/2 W | 6100-3515 | 01121 | RC20GF5131 | 5905-279-3496 |
| R10 | Composition, 220 Ω ±5% 1/2 W | 6100-1225 | 01121 | RC20GF221 | 5905-279-3513 |
| R11 | Composition, 430 Ω ±5% 1/2 W | 6100-1435 | 01121 | RC20GF431J | 5905-279-3512 |
| RECTIFIE | RS | | | | |
| RX1 | | 6080-2800 | 77638 | 219 | |
| RX2 | | 6080-2700 | 77638 | 6VI | |
| RX3 | | 6080-2900 | 77638 | 612 | |
| RX4 | | 6080-2500 | 77638 | IVI | |
| RX5 | | 6080-2600 | 77638 | 3YI | |
| SWITCH | | | | | |
| SI | Toggle | 7910-1300 | 04009 | 83053-SA | 5930-909-2510 |
| | | 1210 1300 | 51007 | 00000 041 | 0100 202 3310 |

0746-4310 24655 0746-4310

1262-B PARTS LIST



Figure 13. Schematic Diagrom, Type



Figure 14. Layout of Components on Etched Board.



c Diagram, Type 1262-B Power Supply.





FEDERAL MANUFACTURER'S CODE

From Federal Supply Code for Manufacturers Cataloging Handbooks H4-1 (Name to Code) and H4-2 (Code to Name) as supplemented through August, 1968.

Manufacture

Code

99800

Code

Code Manufacturer Jones Mfg. Co, Chicago, Illinois Walso E lieutronics, Sorburg, L.I., N.Y. Aeroxo, Corp, New Balford, Mass. Aliem Products Co, Brockhurg, L.I., N.Y. Aeroxo, Corp, New Balford, Mass. Aliem Products Co, Brockhurg, L.I., N.Y. Aeroxo, Corp, Suagerics, Mass. Tarzet Instruments, Inc, Dalas, Texes Ferroscube Corp, Saugerics, N.Y. 12707 Ferwal Lab Inc, Morton Grove, III. Fastex, Das Plaines, III, 60016 GL: Semicon Prod, Syracuse, N.Y. 13201 Grayburne, Yonker, N.Y. 13701 Protein Relation Corp, Server, N. N. Arrow-Hart & Hegeman, Hartford, Corn, 06106 Motorola, Preenia, Arz, 85008 Engré E lieuten, Inc, Washid, Mass, 01800 Digitron Co, Pasedema, Calif. Engle Signal EW, Bills Co), Baroon, Misc. Arrow-Hart & Hegeman, Hartford, Corn, 06106 Motorola, Preenia, Arz, 85008 Engré E lieute, Inc, Washidi, Mass, 01890 Digitron Co, Pasedema, Calif. Arres Semicond, Arlington Hts, III, 60004 Bortonic Corp, Hawtorne, Coll. Fatochild Camera, Mourian View, Calif. Birtche Corp, Hawtorne, Coll. Start East, Inc, Washidi, Mass, 01800 Borg Int, Delevan, Was, 53115 Wart Tomora, G. Geregoton, Mass. 05106 Bodine Electro, Corp, Hawtform, Coll. Start Tomora, G. Geregoton, Mass. 01830 Burges Battary Co, Freeport, III. Start East, Inc, Savitario, N.J. Gerss Comp, V. Hartford, Conn, National Semiconductor, Bartford, Conn, National Semiconductor, Bartford, Conn, National Semiconductor, Mass. 01300 Burges Battary Corp, Hawtford, N.J. Gray Savitari Morg, N.S. Gurton Devices, Tappan, N.Y. 10903 Burges Battary Corp, Hautford, N.J. Gray Savitari, Corp, Hautford, Conn, National Semiconductor, Bartford, Conn, National Semiconductor, Nathford, N.J. Gray Savitari, Corp, Hautford, Conn, Mathema, Savitary Corp, Hautford, Conn, Mathema, Savitar, Savitar, Savitar Gray Mathema, Savitar, Savitar Gray Savitar, Corp, Hautford, Conn, National Semiconductor, Nathford, N.Y. General Instrument Corp, Hautware, Wass, 52230 Stinger Corp, Johi Doy, Saverned, Mass, 502140 Gray Mathema, N.Y. 10320 Gray Davies, Tappan, N.Y. 00434 00656 01121 01295 02114 02660 02768 03508 03888 03911 04009 05170 05624 05820 07126 07127 07263 07387 07595 07626 07829 07910 07983 08730 09213 09408 11236 11599 12498 12672 12697 12954 13327 14433 14655 14674 14936 15238 15605 17771 19396 19644 21335 22753 23342 24446 24454 24455 26806 28520 28959 30874 32001 33173 35929 Constants Co, Mont, 19, Que, P.R. Mallory & Co Inc., Indianepolis, Ind. Martin-Rockwell Corp. Jamestown, N.Y. Honeywell Inc, Minnepolis, Minn, 55408 Muter Co, Chicago, III, 60638 National Co, Inc. Melrose, Mass. 02176 Norme-Hoffman, Stanford, Conn. 06904 38443 40931 42190 42498 43991

RCA, New York, N.Y. 10020
 Raytheon Mg Co. Waitham, Muss. 20154
 Shallerose Mg Co. Santa, N.C.
 Shallerose Mg Co. Santa, N.C.
 Shallerose Mg Co. Santa, N.C.
 Shaytey Eliteric Co. N. J. Advini, Mass.
 Thomas and Betts Co., Elitabein, N.J. 07207
 Thwi Inci, Accessorias Di, Claveland, Oho
 Torington Mg Co., Elitabein, N.J. 07207
 Unitor Carbidic Goro, New York, N.Y. 10017
 Unitor Carbidic Coro, New York, N.Y. 10017
 Helden Mg Co., Chicago, Ill, 6064
 Bromson, Homer D, Co., Bescon Fails, Conn, Carfield, H.O. Co, Clitton Forey, V.J. 24422
 Bustram (McGawe Editon), St., Louis, Mo, 1TT Cannon Elee, L.A., Calif, 30031
 Controll Carbon Co, Inc, New York, N.Y. 10017
 Chicago Minaturu Lamp Works, Chicago, Ill. Gorago, Ill.

Manu facturer Air Filter Corp, Milwaukee, Wisc, 53218 Hammarlund Co, Inc, New York, N.Y. Beckman Instruments, Inc. Yorke, Collit. International Instrument, Carage Conn. Beckman Instruments, Inc. Yorke, Coll. Instructional Instrument, Carage Conn. Solantia Mrw. Mol Corp. Stuffer, N.J. 07960 Millary Specifications Columbus Electronics Corp. Yonkers, N.Y. Filtron Co, Fubing, L.I., Yu, 1135a Ledex Inc, Davion, Ohio 45402 Berry-Wing Toor, Watertown, Mass, Sylvana Electronics Corp. Yonkers, Laford, Ind. Indiana Patterns & Model Works, Laford, Ind. Metals & Controls Inc, Attleborg, Mass. Millawa Patterns & Model Works, Laford, Ind. Metals & Controls Inc, Attleborg, Mass. Millawa Patterns & Model Works, Laford, Ind. Metals & Controls Inc, Attleborg, Mass. Millawa Patterns & Model Works, Laford, Ind. Gener Eatterns Co, Cambridge, Mass. Victory Engineering, Springfield, N.J. 07081 Bearing Special VCo, San Francisco, Calif. Solar Electric Corp. Warren, Penn, Union Caralie Corp. New York, N.Y. 10017 National Electronics Inc, Geneva, III. TAW Capacity Du, Qalala, Nebr. Life Corp. New Rochelle, Ny. 1, 10201 Cont Electronics Corp. Brockivn, N.Y. 11222 Cutter-Hammer Inc, Lincolin, III. Gould Nat, Batterns Inc, Trenton, N.J. Cornell-Dublier, Fuausy York, N.Y. 11222 Cutter-Hammer Inc, Lincolin, III. Gould Nat, Batterns Inc, Trenton, N.J. Cornell-Dublier, Fuausy York, N.Y. 11222 Cutter-Hammer Inc, Lincolin, III. Gould Nat, Batterns Inc, Trenton, N.J. Cornell-Dublier, Fuausy York, N.Y. 11222 Cutter-Hammer Inc, Lincolin, III. Gould Nat, Batterns Inc, Trenton, N.J. Cornell-Dublier, Fuausy York, N.Y. 11031 Contineed Drow Rockelle, N.Y. 1003 Augel Inc, Artleborg, Mass. 20703 Chanadar Co, Nethersfield, Sonn, 06109 Line functioner, Wookide, L.J. N.Y. EG. Gong, Weithersfield, Conn, 06109 Augel Inc, Artleborg, Mass. 20703 Chanadar Co, Weithersfield, Conn, 06109 Augel Inc, Artleborg, Mass. 20703 Chanadar Co, Weithersfield, Conn, 06109 Augel Inc, Artleborg, Mass. 20703 Chanadar Co, Weithersfield, Conn, 06109 Augel Inc, Artleborg, Mass. 20703 Chanadar Co,

9/68

.



Syrgcuse, New York 13211 Telephone 315 454-9323

NEW ENGLAND*

22 Baker Avenue West Concord, Massachusetts 01781 Telephone 617 646-0550

PHILADELPHIA

Fort Washington Industrial Park Fort Washington, Pennsylvania 19034 Telephone 215 646-8030

WASHINGTON* AND BALTIMORE

11420 Rockville Pike Rockville, Maryland 20852 Telephone 301 946 1600

ORLANDO

113 East Colonial Drive Orlando, Florida 32801 Telephene 305 425-4671

* Repair services are available at these district offices.

LOS ANGELES*

1000 North Seward Street Los Angeles, California 90038 Telephone 213 469-6201

AN FRANCISCO

626 San Antonio Road Mountain View, California 94040 Telephone 415 948-8233

DALLAS*

2600 Stemmons Freewoy, Suite 210 * Dallas, Texas 75207 Telephone 214 637-2240

TORONTO*

99 Floral Parkway Toronto 15, Ontorio, Canada Telephone 416 247 2171

MONTREAL

1255 Laird Boulevard Town of Mount Royal, Quebec, Canada Telephone 514 737-3673 OTTAWA Telephone 61 3 233-4237

General Radio Company (Overseas), 8008 Zurich, Switzerland General Radio Company (U.K.) Limited, Bourne End, Buckinghamshire, England **Representatives in Principal Overseas Countries**

Printed in USA